



Lear 35 Exterior Kit PAGE 1 of 3

NOTE: Modifications and changes to accomodate your specific aircraft will be made at **NO EXTRA CHARGE**.
Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1100 AMPERES UN MAXIM DE 1100 AMPERES</p>	<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1100 AMPERES UN MAXIM DE 1100 AMPERES</p>
<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1100 AMPERES UN MAXIM DE 1100 AMPERES</p>	<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1100 AMPERES UN MAXIM DE 1100 AMPERES</p>
<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1500 AMPERES UN MAXIM DE 1500 AMPERES</p>	<p>EXTERNAL POWER 1500 AMPERES MAXIMUM UN MAXIMUM DE 1500 AMPERES UN MAXIM DE 1500 AMPERES</p>
<p>EXTERNAL POWER 1100 AMPERES MAXIMUM UN MAXIMUM DE 1500 AMPERES UN MAXIM DE 1500 AMPERES</p>	<p>EXTERNAL POWER 1500 AMPERES MAXIMUM UN MAXIMUM DE 1500 AMPERES UN MAXIM DE 1500 AMPERES</p>

<p>GATES LEARJET SPOILER ACTUATOR P/N 2417015-1 S/N</p> <p>OPERATING PRESSURE 1500 PSIG HYDRAULIC FLUID MIL-H-5606 CAUTION - INTERNAL SPRING LOCKS</p>	<p>INSTALL FUEL CROSSFLOW CHECK VALVES (WITHIN WING TANK) WITH FLOW DIRECTION OUTBOARD</p>	<p>STALL VANE</p> <p>STALL VANE</p>
--	--	-------------------------------------

<p>GATES LEARJET LDG GR UPLOCK ACTUATOR P/N 2417016-1 S/N</p> <p>OPERATING PRESSURE 1500 PSIG HYDRAULIC FLUID MIL-H-5606</p>	<p>ANGLE OF ATTACK INDICATOR</p>	<p>LIFT</p> <p>LIFT</p> <p>LIFT</p>
--	--------------------------------------	-------------------------------------

FUEL JET A
369 GALS. TOTAL
FUEL MUST CONTAIN PFA 55 MB ADDITIVE
SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY
OF ADDITIVES AND FUELING PROCEDURES

FUEL JET A
369 GALS. TOTAL
FUEL MUST CONTAIN PFA 55 MB ADDITIVE
SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY
OF ADDITIVES AND FUELING PROCEDURES

FUEL JET A
375 GAL TOTAL (EXCLUDES FUS. TANK)
575 GAL TOTAL (INCLUDES FUS. TANK)
FUEL MUST CONTAIN PFA 55 MB ADDITIVE
SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY
OF ADDITIVES AND FUELING PROCEDURES

FUEL JET A
375 GAL TOTAL (EXCLUDES FUS. TANK)
575 GAL TOTAL (INCLUDES FUS. TANK)
FUEL MUST CONTAIN PFA 55 MB ADDITIVE
SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY
OF ADDITIVES AND FUELING PROCEDURES

FUEL
404 GAL TOTAL - WING TANKS ONLY
600 GAL TOTAL - INCLUDES FUSE TANK
SEE FLIGHT MANUAL FOR TYPE OF FUEL
AND FUELING PROCEDURE

↗	OPEN	SEE FLIGHT MANUAL FOR APPLICABLE OIL
↗	OPEN	SEE FLIGHT MANUAL FOR APPLICABLE OIL
↗	OPEN	SEE FLIGHT MANUAL FOR APPLICABLE OIL
↘	PITOT STATIC PUSH TO DRAIN	FUEL VENT DRAIN SHOULDER STATIC PUSH TO DRAIN
↘	PITOT STATIC PUSH TO DRAIN	FUEL VENT DRAIN SHOULDER STATIC PUSH TO DRAIN
↘	PITOT STATIC PUSH TO DRAIN	FUEL VENT DRAIN SHOULDER STATIC PUSH TO DRAIN
↘	PITOT STATIC PUSH TO DRAIN	FUEL VENT DRAIN
↘	PITOT STATIC PUSH TO DRAIN	EXTERNAL POWER 28 VOLTS D.C.
↘	FUEL VENT PUSH TO DRAIN	EXTERNAL POWER 28 VOLTS D.C.
↘	FUEL VENT PUSH TO DRAIN	EXTERNAL POWER 28 VOLTS D.C.
↘	FUEL VENT PUSH TO DRAIN	EPR SYSTEM PUSH TO DRAIN
↘	FUEL VENT PUSH TO DRAIN	FUEL COMPUTER
↘	FUEL VENT PUSH TO DRAIN	FUEL COMPUTER

<p>AEROGRAPHICS 800-336-9633</p>	<p>LEARJET 35 EXTERIOR PLACARD KIT</p>	<p>METHYL ALCOHOL PER O-M-232 GRADE A</p>
--------------------------------------	--	---

CAUTION
DO NOT REMOVE OIL TANK CAP WHEN OIL IS HOT AND SIGHT GLASS INDICATES FULL

CAUTION
DO NOT REMOVE OIL TANK CAP WHEN OIL IS HOT AND SIGHT GLASS INDICATES FULL

CAUTION
DO NOT REMOVE OIL TANK CAP WHEN OIL IS HOT AND SIGHT GLASS INDICATES FULL

<p>GATES LEARJET BRAKE ASSY NUMBER 6600330-2</p>	<p>GATES LEARJET WHEEL ASSY NUMBER 6600330-1</p>
--	--

<p>1.75 GAL. CAP. METHYL ALCOHOL PER O-M-232 GRADE A</p>	<p>EXTERNAL POWER 1000 AMPERES MAXIMUM UN MAXIMUM DE 1000 AMPERES UN MAXIM DE 1000 AMPERES</p>	<p>EXTERNAL POWER 1000 AMPERES MAXIMUM UN MAXIMUM DE 1000 AMPERES UN MAXIM DE 1000 AMPERES</p>
--	--	--

FILLER EMERGENCY GAS BOTTLE
CAUTION: HIGH PRESSURE. USE ONLY CLEAN DRY AIR OR NITROGEN. FILL TO 1800 - 3000 P.S.I.



Lear 35 Exterior Kit PAGE 2 of 3

NOTE: Modifications and changes to accommodate your specific aircraft will be made at **NO EXTRA CHARGE**.
Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

STATIC VENTS KEEP CLEAR	DOOR LOCKED	CAUTION DO NOT MIX BRANDS OF OIL
STATIC VENTS KEEP CLEAR	DOOR LOCKED	CAUTION DO NOT MIX BRANDS OF OIL
STATIC VENTS KEEP CLEAR	OXYGEN DISCHARGE	
STATIC VENTS KEEP CLEAR		
OIL FILLER ACCESS	OIL FILLER ACCESS	NO STEP
PITOT STATIC PUSH TO DRAIN	PITOT STATIC PUSH TO DRAIN	NO STEP
PITOT STATIC PUSH TO DRAIN	PITOT STATIC PUSH TO DRAIN	
TRANSFER LINE MOISTURE DRAIN	TRANSFER LINE MOISTURE DRAIN	
FUEL COMPUTER DRAIN	FUEL COMPUTER DRAIN	
FUEL FILTER DRAIN	FUEL FILTER DRAIN	FUEL FILTER DRAIN
FUEL FILTER DRAIN	FUEL FILTER DRAIN	FUEL FILTER DRAIN
FUSELAGE SUMP MOISTURE DRAIN	FUSELAGE SUMP MOISTURE DRAIN	
SHOULDER STATIC PUSH TO DRAIN	SHOULDER STATIC PUSH TO DRAIN	
EXPANSION LINE	EXPANSION LINE	
DOOR LOCKED	DOOR LOCKED	TRANSFER LINE TRANSFER LINE

FUEL 375 GAL TOTAL (EXCLUDES FUS. TANK) 575 GAL TOTAL (INCLUDES FUS. TANK) FUEL MUST CONTAIN PFA 55MB ADDITIVE JP-4 OR EQUIVALENT SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY OF ADDITIVES AND FUELING PROCEDURES	FUEL 369 GAL TOTAL FUEL MUST CONTAIN PFA 55MB ADDITIVE JP-4 OR EQUIVALENT SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY OF ADDITIVES AND FUELING PROCEDURES
FUEL 369 GAL TOTAL FUEL MUST CONTAIN PFA 55MB ADDITIVE JP-4 OR EQUIVALENT SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY OF ADDITIVES AND FUELING PROCEDURES	RIGHT ENGINE FUEL PUSH TO DRAIN FUEL VENT PUSH TO DRAIN RIGHT ENGINE FUEL PUSH TO DRAIN MOISTURE DRAIN RIGHT ENGINE FUEL PUSH TO DRAIN MOISTURE DRAIN RIGHT ENGINE FUEL PUSH TO DRAIN LIFT RIGHT ENGINE FUEL PUSH TO DRAIN LIFT
FUEL 375 GAL TOTAL (EXCLUDES FUS. TANK) 575 GAL TOTAL (INCLUDES FUS. TANK) FUEL MUST CONTAIN PFA 55MB ADDITIVE JP-4 OR EQUIVALENT SEE FLIGHT MANUAL FOR TYPES OF FUEL QUANTITY OF ADDITIVES AND FUELING PROCEDURES	LEFT ENGINE FUEL PUSH TO DRAIN LIFT LEFT ENGINE FUEL PUSH TO DRAIN MOISTURE DRAIN LEFT ENGINE FUEL PUSH TO DRAIN MOISTURE DRAIN LEFT ENGINE FUEL PUSH TO DRAIN
FUEL CROSSOVER FUEL CROSSOVER FUEL CROSSOVER FUEL CROSSOVER	LEFT ENGINE FUEL PUSH TO DRAIN

CAUTION DORSAL OXYGEN BOTTLE MUST BE TURNED OFF FIRST GATES LEARJET BRAKE ASSY NUMBER 6600330-2 GATES LEARJET WHEEL ASSY NUMBER 6600330-1	FILLER EMERGENCY GAS BOTTLE CAUTION: HIGH PRESSURE. USE ONLY CLEAN DRY AIR OR NITROGEN. FILL TO 1800-3000 P.S.I.
FUEL 209 GAL. TOTAL FUEL 209 GAL. TOTAL - EXCLUDES FUS. TANK 406 GAL. TOTAL - INCLUDES FUS. TANK	FUEL JET A, JET A-1, MIL. 1 27686 SEE AIRPLANE FLIGHT MANUAL FOR ALTERNATE FUEL AND FUELING PROCEDURES
FILLER EMERGENCY GAS BOTTLE CAUTION: HIGH PRESSURE USE ONLY CLEAN DRY AIR OR NITROGEN. FILL TO 1800-3000 P.S.I.	FUEL JET A, JET A-1, MIL. 1 27686 SEE AIRPLANE FLIGHT MANUAL FOR ALTERNATE FUEL AND FUELING PROCEDURES
FUEL 404 GAL. TOTAL - WING TANK ONLY 600 GAL. TOTAL - INCLUDES FUS. TANK SEE FLIGHT MANUAL FOR TYPE OF FUEL AND FUELING PROCEDURE	CAUTION FUEL WILL OVERFLOW IF CAP IS REMOVED AFTER TRANSFERING FUEL TO FUEL WING TANK

↑ WINDSHIELD ONLY FILL TO
ONE GALLON MARK

WINDSHIELD AND NOSE
FILL TO TOP

R E M O V E R E M O V E
B E F O R E B E F O R E
F L I G H T F L I G H T

AeroGraphics

The Original Aircraft Lettering Company



Lear 35 Exterior Kit PAGE 3 of 3

NOTE: Modifications and changes to accomodate your specific aircraft will be made at **NO EXTRA CHARGE**.
Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

FUEL JET A

364 GAL TOTAL (EXCLUDES FUS. TANK)
559 GAL TOTAL (INCLUDES FUS. TANK)

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE

SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

FUEL JET A

364 GAL TOTAL (EXCLUDES FUS. TANK)
559 GAL TOTAL (INCLUDES FUS. TANK)

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE

SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

FUEL DRAIN

TO DRAIN - PUSH POPPET UP AND ROTATE 90° CW OR CCW UNTIL LOCK
TO CLOSE - ROTATE POPPET APPROX 90° CW OR CCW UNTIL LOCK
TO REPLACE SEAL - PUSH POPPET UP APPROX. .03 AND ROTATE CW
UNTIL STOP AND RELEASE
TO CLOSE - REVERSE PROCEDURE FOR NORMAL POSITION RETURN

FUEL JET A

364 GALS. TOTAL

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE

SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

FUEL JET A

364 GALS. TOTAL

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE

SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

JET FUEL ONLY

JP-4 OR EQUIV

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE



369 GAL TOTAL (EXCLUDES FUS. TANK)
569 GAL TOTAL (INCLUDES FUS. TANK)
SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

FUEL DRAIN

TO DRAIN - PUSH POPPET UP AND ROTATE 90° CW OR CCW UNTIL LOCK
TO CLOSE - ROTATE POPPET APPROX 90° CW OR CCW UNTIL LOCK
TO REPLACE SEAL - PUSH POPPET UP APPROX. .03 AND ROTATE CW
UNTIL STOP AND RELEASE
TO CLOSE - REVERSE PROCEDURE FOR NORMAL POSITION RETURN

FUEL DRAIN

TO DRAIN - PUSH POPPET UP AND ROTATE 90° CW OR CCW UNTIL LOCK
TO CLOSE - ROTATE POPPET APPROX 90° CW OR CCW UNTIL LOCK
TO REPLACE SEAL - PUSH POPPET UP APPROX. .03 AND ROTATE CW
UNTIL STOP AND RELEASE
TO CLOSE - REVERSE PROCEDURE FOR NORMAL POSITION RETURN

JET FUEL ONLY

JP-4 OR EQUIV

FUEL MUST CONTAIN
PFA 55 MB ADDITIVE



369 GAL TOTAL (EXCLUDES FUS. TANK)
569 GAL TOTAL (INCLUDES FUS. TANK)
SEE FLIGHT MANUAL FOR TYPES OF FUEL
QUANTITY OF ADDITIVES AND
FUELING PROCEDURES

CAUTION
STAY CLEAR OF
SPOILERONS

SEE MAINTENANCE MANUAL
FOR MAINTENANCE INSTRUCTIONS

CAUTION
STAY CLEAR OF
SPOILERONS

SEE MAINTENANCE MANUAL
FOR MAINTENANCE INSTRUCTIONS

CAUTION
STAY CLEAR OF
SPOILERONS

SEE MAINTENANCE MANUAL
FOR MAINTENANCE INSTRUCTIONS

EMERGENCY EXIT
RELEASE HANDLE & TURN

EMERGENCY EXIT
RELEASE HANDLE & TURN

CAUTION
STAY CLEAR OF
SPOILERONS

SEE MAINTENANCE MANUAL
FOR MAINTENANCE INSTRUCTIONS

EMERGENCY EXIT
PUSH BUTTON
PULL HANDLE
TO RELEASE

CAUTION

BOLT THRU FLAP SECTOR AND PUSHROD
MUST BE INSTALLED WITH HEAD DOWN 

CAUTION

 BOLT THRU FLAP SECTOR AND PUSHROD
MUST BE INSTALLED WITH HEAD DOWN

FIRE EXT DISCHARGE
FIRE EXT DISCHARGE

FIRE EXT DISCHARGE FIRE EXT DISCHARGE

GATES LEARJET
SPOILER ACTUATOR
P/N 2417015-1
S/N

OPERATING PRESSURE 1500 PSIG
HYDRAULIC FLUID MIL-H-5606
CAUTION - INTERNAL SPRING LOCKS

GATES LEARJET
LDG GR UPLOCK ACTUATOR
P/N 2417016-1
S/N

OPERATING PRESSURE 1500 PSIG
HYDRAULIC FLUID MIL-H-5606

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065